



Lever Style Vent-Drain Installation Instructions

- 1) Screw the Vent-Drain into the 3/4NPT hole in the casting.
There is pipe thread sealant on the Vent-Drain threads already.
- 2) Screw the 1/2" hose barb fitting into the hole in the Vent-Drain body.
Use thread locking compound, pipe dope, or Teflon tape on the threads of the barb fitting.

VERY IMPORTANT:

LEAVE A MINIMUM OF 1 3/8 INCH (35 mm) OF THE BARB FITTING VISIBLE.



**If the barb fitting is screwed in too far
it will make the lever difficult or impossible to turn!**

TASK FORCE TIPS, Inc.
MADE IN USA • www.tft.com

2351 Industrial Drive, Valparaiso, IN 46383-9511 USA
800-348-2686 • 219-462-6161 • Fax 219-464-7155